


# STREET GUARDIAN FIRMWARE UPGRADE

1. Fully charge the battery to prevent any failure caused by running out of power during upgrade, any upgrade failure will need reprogramming.
2. Format the Micro SD Card
3. Copy the “SD\_A72.bin” file into the Micro SD card
4. Insert the Micro SD and turn ON the camera
5. The display will show



6. Wait until the camera turn OFF automatically
7. Remove the Micro SD and delete the File (SD\_A72.bin)
8. Now the upgrade procedure is finished.